

# TS III Qualifier

## Operation Manual



ASG, Division of Jergens Inc.  
Jergens Way  
15700 S. Waterloo Road  
Cleveland, OH 44110-3898  
Tel: (216) 486-6163  
Toll-Free: (888) 486-6163  
Fax: (216) 481-4519  
E-mail: [asginfo@asg-jergens.com](mailto:asginfo@asg-jergens.com)  
[www.asg-jergens.com](http://www.asg-jergens.com)

## Table of Contents

<b>INTRODUCTION</b> .....	<b>3</b>
CONFIGURATION .....	3
<b>WARNINGS &amp; CAUTIONS</b> .....	<b>4-5</b>
<b>QUICK START GUIDE</b> .....	<b>6-7</b>
<b>CONTROL PANEL</b> .....	<b>8-9</b>
<b>CONNECTION PROCEDURE</b> .....	<b>10</b>
<b>INTERFACE NAVIGATION GUIDE</b> .....	<b>11-37</b>
POWER UP SEQUENCE .....	11
HOME SCREEN .....	12-14
BASIC OPERATIONS .....	15
Reset Batch .....	15
ADVANCED OPERATIONS .....	16-37
Password & Keyswitch .....	16
Program Menu .....	17-18
AutoCal Procedure .....	19-20
Timer Min .....	21
Timer Max .....	22
Timer Bump .....	23
Start Current .....	24
Min Current .....	25
Max Current .....	26
Batch Count .....	27
Globalize .....	28
Relay & Beep .....	29
Parameter Select .....	30
Count Direction .....	31
New Password .....	32
Digital Inputs .....	33
Current Draw .....	34
View Run Time .....	35
View Shutoff I .....	36
LCD Contrast .....	37
<b>SOFTWARE (CYBER QUALIFIER)</b> .....	<b>38-39</b>
<b>OPERATIONS GRAPHS</b> .....	<b>40-44</b>
<b>SPECIFICATIONS</b> .....	<b>45-46</b>
I/O SPECIFICATIONS .....	46
<b>TROUBLESHOOTING</b> .....	<b>47-48</b>
<b>INDEX</b> .....	<b>49-51</b>

## Introduction

---

Thank you for purchasing ASG's TS III Qualifier. The following sections describe WARNINGS and CAUTIONS for using our product. Make sure to read these sections before using the TS III Qualifier. As with any electrical product, mishandling the TS III Qualifier could cause damage to the TS III component or cause physical injury to the individual. Proper care must be used at all time when operating or servicing the TS III Qualifier. In addition to these sections, carefully read the Set-up Procedure and Interface Navigation Guide to ensure proper usage.

The Interface Navigation Guide is broken down into sections: controls that are accessible while the TS III Qualifier is Locked (Advance Operations), and Unlocked (Basic Operations).

This operation manual is designed for both the BL and CL style TS III Qualifiers. Throughout this manual all features are included in both models unless noted otherwise.

This operation manual is designed for the general operation of the TS III Qualifier. If any additional questions or concerns should arise, please contact your local ASG representative.

Please check parts prior to use. If anything is missing or damaged, contact your local ASG representative.

### Configuration

TS III Qualifier.....	One Piece
Power Cord.....	One Piece
Keys.....	Two Keys
Operation Manual.....	One Copy

## Warning

### Make sure to read this section

If these instructions are ignored, and the product is handled inappropriately, serious injury could occur.



Whenever disassembling the unit make sure power has been turned off and the power cord is removed from the outlet. There is a high electrical voltage inside the unit that could cause an electric shock, failure, or fire.

If you have not worked on or are not familiar with electrical components having a transformer and printed circuit boards we suggest that you return the TS III Qualifier directly to ASG for service, modification or changeover.



If an abnormal odor, unusual sound or smoke is observed, stop using the product, unplug it immediately and contact your ASG representative.



Do not allow any type of liquid to come in contact with any part of the unit, because it could result in an electrical shock or fire.

Fully insert all plugs into their proper receptacle. Insufficient contact may generate heat that could result in a fire or electrical shock.

Do not fold, bend, or impose excessive force on the cord. Excessive force on the cord may cause a short-circuit, which could result in a fire or electrical shock.

While inserting or removing the plugs don't pull on the cords. This action could result in a disconnection or a broken plug. Make sure to hold the plug body during insertion and removal.

## ■ Cautions

---


If these instructions are ignored and the product is handled inappropriately, bodily injury or property damage could occur.

- This unit accepts an AC input voltage from 100VAC to 240VAC. Trying to operate this unit with a voltage outside that range may cause damage to the unit.
- Do not place the product in an unstable location. Dropping the unit could result in damage to the TS III Qualifier.
- Do not place or store the unit in a location with moisture or dust, to prevent possible fire or failure.
- When moving the TS III Qualifier, make sure to turn OFF the power and remove the power plugs.
- Before maintenance, make sure to turn OFF the power and remove the power plugs.
- There are no user serviceable parts inside the main enclosure of the TS-III Qualifier.
- As with any printed circuit boards proper care and knowledge is critical if a customer attempts to service the TS III unit. Damage occurring to the electrical components by the customer attempting to service the unit voids all warranties and all work performed is the sole responsibility of the customer.

## Quick Start Guide

### **Warning:**

Make sure to review the WARNINGS and CAUTIONS sections located on pages 4 and 5 before using the TS III Qualifier.




### **Step 1:**

Power up the unit waiting for the Home Screen (See pages 11-14) to appear. During power-up the device will identify the tool type for which the unit is configured (either BRUSH or BRUSHLESS). Be sure that the tool to be used with this device matches the tool type.

- TS-III BL Qualifier, Part Number - 66517
- TS-III CL Qualifier, Part Number - 66515

### **Step 2:**

Attach one end the cord to the tool and the other end to the TS III Qualifier tightening the knurled knob. Select the desired tool speed (HI or LO). Turn the Soft Start either ON or OFF (Note: The Soft Start only work with brush style tools).




### **Step 3:**

Press the enter (ENT) button and enter the Programming Menu. Either use the Arrow keys to insert password (0104 default) or bypass the password by turning the key to the programming position (Horizontal).

Continued on the next page....

## Quick Start Guide



### Step 4:

Use the arrow keys to navigate to the AutoCal option in the Program Menu. Once at the AutoCal option, press the enter (ENT) button to select it.

### Step 5:

The unit will prompt the operator (B-LESS or BRUSH) TOOL OFF Press ENT Key. Make sure the tool is not running and press the ENT Key. The unit will count down 5s..thru..1s compensating for any background noise and automatically advances to the next screen.

### Step 6:

After the count down is finished the display will prompt the user to run a fastener, the display should read ACAL (either B-LESS or BRUSH) TOOL Run Fastener. Run the tool on the target fastener allowing the clutch to turn the tool off. After the clutch fires, the display should read AUTOCAL COMPLETE Press Any Key.

If a successful run down is not completed the user will not advance to the next screen. Another target fastener should be run again allowing the tool clutch to turn the tool off.

After AUTOCAL COMPLETE Press Any Key is displayed, pressing a key will return the operator to the Program Menu.

### Step 7:

Any of the Advanced Operations can be adjusted including: Timer Bump, Batch Count, Count Direction, etc. (See pages 16-37)

### Step 8:

When finished editing parameters press the ESC button to lock the unit and return to the Display/Run Screen.


### Step 9:

Run several fasteners to ensure that the unit is working properly. If everything appears to be working, production can begin.

## Control Panel

### Control Panel:

Most of the buttons required to operate the TS III Qualifier are located on the Control Panel. Each of the button's functions will be described in detail later in this operation manual.



The four arrow buttons (UP, DOWN, LEFT, and RIGHT) are used during programming. The arrow keys are used to navigate through menus, raise and lower values during programming, and move the cursor to select items that need to be edited.



The ENT button has a wide variety of functions including: saving parameters, selecting an items, changing screens, and continuing through different operations.




The ESC button also has an assortment of functions including: exiting screens without saving, and canceling operations.



## Control Panel

### Front Panel:




The five pin circular connector is used to supply power to a tool and also to read signals back from the tool.

The Soft Start switch turns the Soft Start feature ON and OFF. If the Soft Start feature is enabled, the tool will

spin slowly for a revolution or two before increasing to full speed. (Note: Can only be enabled with brush tools.)

Tool speed is governed by the Speed switch. When this switch is in the HI setting, the VDC out will be 30VDC. On the LO setting, the power supply provides 20VDC. The tool's speed is directly proportional to output voltage. (Refer to the ASG catalog for tool speeds)

### Rear Panel:



The main power switch for the unit and the power entry module are found on the rear panel. This unit is capable of running on an AC input voltage of 100VAC to 240VAC.

The keyswitch allows a user to reach the programmable functions without entering a password.

The unit's beeper provides audible feedback when rejects occur and can provide a double –beep when a batch accept occurs (See page 29).

The RS-232 port can be used as a secondary means of programming the unit or getting information from the unit. (See page 45 - 48)

The 12 Pin I/O Connector contains several input and output functions. (See page 46 for more details)

## ■ Connection Procedure

---

### Connection Procedure


The following are general guidelines for connecting the TS III Qualifier. Specific programming instructions are described in the Interface Navigation Guide. (See pages 11-37)

1. Plug the tools power cord into the rear of the electric screwdriver and then the front of the TS III Qualifier.
2. Plug the AC cord into the rear of the TS III Qualifier and then into the wall.
3. Verify that all connections are secure.
4. Flip the Qualifier's main power switch to the ON position.
5. The unit should begin the Power Up Sequence (See page 11).
6. When the TS III Qualifier brings up the Home Screen (See page 12-14), it is ready for programming.

## Interface Navigation Guide

### Power-Up Sequence & Home Screen


When the unit is powered up, the LCD will display the following screens and then proceed to the Home Screen.




## Interface Navigation Guide

### Home Screen/Display Panel


There are three screens associated with the home screen/ display panel. Pressing either the UP or DOWN arrow keys will allow the user to change the view on the LCD screen.



The first of these screens shows the current parameter set, status of the last fastening, current count and the number of fasteners in the batch.



The second display screen shows current parameter set, status of last fastener, and total completed batches.



The third display screen shows current parameter set, total completed batches, current count, and number of fasteners in a batch.

## Interface Navigation Guide

---

### Home Screen/Display Panel

The following displays will appear while the unit is in production.

A: STATUS	CNT / BAT
NONE	0 / 3

 } View while waiting for production to begin

A: STATUS	CNT / BAT
IN CYCLE	0 / 3

 } View during rundown (in-cycle)

A: STATUS	CNT / BAT
CYCLE OK	2 / 3

A: STATUS	CNT / BAT
BATCH OK	3 / 3

 } ACCEPT Statuses

Cyc Acc: indicates that the previous rundown was successful. A successful rundown will increase the count and fire the Accept light.

Bat Acc: indicates the previous Batch has been completed and accepted. A complete batch will be accompanied by a double beep along with the Batch light illuminating.

## Interface Navigation Guide

---

### Home Screen/Display Panel

The following displays will appear while the unit is in production and an error/reject is generated.

A: STATUS	CNT / BAT
REJ TMin	1 / 3

A: STATUS	CNT / BAT
REJ TMax	1 / 3

A: STATUS	CNT / BAT
REJ TClu	1 / 3



REJECTS will be described by their corresponding message.

Tmin: The tool was unable to run long enough to satisfy the minimum time parameter.

Tmax: The tool passed the maximum time parameter.

Tclu: The tool's clutch did not engage.

A: STATUS	CNT / BAT
REJ IMin	1 / 3

A: STATUS	CNT / BAT
REJ IMax	1 / 3



REJECTS will be described by their corresponding message.

IMin: The tool was unable to draw enough current to satisfy the minimum current parameter when the clutch engaged.

IMax: The tool passed the maximum current parameter when the clutch engaged.

Note: Brushless tools only.

## Interface Navigation Guide

---

### Basic Operations

The following features are only active while the TS III Qualifier is in the locked position.

#### Reset Batch

The Reset Batch will clear the value in the count, resetting it to zero.

A: STATUS	CNT / BAT
NONE	2 / 3

In order to reset the batch the operator must be on the Home Screen.



RESET	BATCH
ENT = YES	ESC = NO

Press the ESC button in order to reset the batch count.

After the ESC button is pressed, the display will read RESET BATCH, ENT=YES ESC=NO.

Use the ENT button to confirm the batch clear and the ESC button to cancel this operation.

After either button is pressed the operator will automatically return to the Home Screen.

#### Change Parameter

The Parameter can be changed through the Keypad or Remotely through the I/O. This section only describes changing the parameter with the Keypad. (Note: This function must be enabled in the Program Menu; see page 30 for changing the Parameter Select (Keypad or Remote I/O).

A: STATUS	CNT / BAT
NONE	0 / 3

In order to change the parameter the operator must be on the Home Screen.



B: STATUS	CNT / BAT
NONE	0 / 3

Pressing either the left or right arrow key the operator will scroll through the eight different parameter options.


After changing the parameter the operator will be immediately ready to run under the new parameter that is selected.

## Interface Navigation Guide

### Advanced Operations

The features listed in the Advanced Operation section of this manual are only accessible while the unit is unlocked. The operator must unlock the unit through one of the two following methods.

#### Password (Default 0104)




Press the ENT key to access the Program Menu. After pressing the ENT button the operator will be prompted to Enter a Password to gain access to the Program Menu and the advanced operations.

Using the left and right arrow keys move the flashing cursor over the asterisk in the password that needs changed. Once the cursor is over the appropriate asterisk the current number in that position will be viewed. Adjust the digit to the proper password with the up and down arrows. Proceed in this manner until all of the desired digits are edited. The default password that ships with all unit is 0104.

After all of the proper digits have been inserted press the ENT key to gain access to the Program Menu

The unit can be locked again by pressing the ESC key.

#### Keyswitch:



Press the ENT key to access the Program Menu. After pressing the ENT button the operator will be prompted to Enter a Password to gain access to the Program Menu and the advanced operations.

Insert the key into the key hole located in the rear of the unit and turn it to the horizontal position. If the keyswitch remains in the horizontal position the Program Menu can be accessed even if the key is removed.

The unit can be locked again by turning the key to the vertical position and pressing the ESC key.



## Interface Navigation Guide

### Advanced Operations

The following features are available only while the unit is unlocked.

### Program Menu



The following is a listing of all options located in the Programming Menu. While in the Program Menu:












- **Arrows (ALL):** advances operator to the next or previous option in the menu
- **ENT:** select the displayed option
- **ESC:** exit the menu



Continued on the next page....


## Interface Navigation Guide

### Program Select Continued From Previous Page

	PROGRAM MENU Batch Count	See page 27 for more information
	PROGRAM MENU Globalize	See page 28 for more information
	PROGRAM MENU Relay & Beep	See page 29 for more information
	PROGRAM MENU Parameter Select	See page 30 for more information
	PROGRAM MENU Count Direction	See page 31 for more information
	PROGRAM MENU New Password	See page 32 for more information
	PROGRAM MENU Digital Inputs	See page 33 for more information
	PROGRAM MENU Current Draw	See page 34 for more information
	PROGRAM MENU View Run Time	See page 35 for more information
	PROGRAM MENU View Shutoff I	See page 36 for more information
	PROGRAM MENU LCD Contrast	See page 37 for more information

## Interface Navigation Guide

### AutoCal™ Procedure



The AutoCal™ is the first option in the Program Menu and is used to quickly set-up specific parameters including Timer Min, Timer Max, and Start Current. The user runs a sample fastener and allows the TS III Qualifier to review the rundown and automatically set the parameter based on that sample fastener. The following steps will walk the operator through the calibration process.




In order to perform an AutoCal enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, AutoCal.

Press the ENT button to perform an AutoCal.



When the screen reads (either B-LESS or BRUSH) TOOL OFF, Press ENT Key, the driver must not be running. The operator should not turn OFF the main power switch or disconnect power to the driver.

Pressing the ENT key is your confirmation that to tool is not running.




After the ENT button is pressed, the display will read ACAL BACKGROUND Time Ys, I = X.X (where Y is a count-down is seconds 5s...4s...3s...2s...1s...and X.X is the background noise that is being compensated).

After all background noise is eliminated the operator will be automatically advanced to the next screen.

Continued on the next page....

## Interface Navigation Guide


### Auto Calibration Continued



Following the unit elimination of background noise the TS III Qualifier will automatically advance to the next screen and should display ACAL (either BRUSH or B-LESS) TOOL, Run Fastener. Be sure that the right type of tool is being used with the unit before proceeding.

The operator will need to rundown the target fastener. The target fastener must match all of the required specifications, because all of the parameter will be based off of the most recent rundown, i.e. the target fasteners. Once the unit witnesses the clutch stopping, all of the timers and threshold will automatically be calculated and stored to non-volatile memory for the parameter set that the unit was in at the beginning of the process.

Automatically following a successful rundown, the profile from the previous sample rundown is loaded. The profile from this sample fastener creates the Timer Min, Timer Max, Start Current and inserts the default into all of the other remaining parameters.




The ESC key can be pressed at any time during this process to abort the ACAL setup and return to the Program Menu without changing the parameter data.

**Note:** If the AutoCal is not working properly please review the Troubleshooting section located on a page 47-48.

## Interface Navigation Guide

### Timer Min



Timer Min defines the minimum amount of time a tool has to run during a fastening process in order to be considered a good fastening. If a fastening process is shorter than Timer Min, a Tmin reject will be issued.

PROGRAM MENU  
Timer Min

In order to edit this value enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Timer Min.

PROGRAM Tmin P:Y  
Timer = XX.XXX

Press the ENT button in order to edit the minimum run timer's value.

After the ENT button is pressed, the display will read PROGRAM Tmin P:Y, Timer = XX.XXX (where Y is the current parameter and XX.XXX is the current timer's value).

Using the left and right arrow keys move the flashing cursor over the digit in the timer value that needs edited. Once the appropriate digit is highlighted, press the up and down arrows to change the digit's value. Proceed in this manner until all of the desired digits are edited.

TIMER MIN SAVED  
Writing....


Once the display shows the appropriate timer value, pressing the ENT button will store the new value to non-volatile memory and the user will be prompted to Press Any Key. At this point any button may be pressed and the unit will return to the Program Menu.

TIMER MIN SAVED  
Press Any Key

During the editing process, if the ESC button is pressed, the unit will abort programming the Timer Min and return to the Program Menu.

## Interface Navigation Guide

### Timer Max



Timer Max defines the maximum amount of time a tool can run during a fastening process and still be considered a good fastening. If a fastening takes longer than Timer Max, a Tmax reject will be issued.

PROGRAM MENU  
Timer Max

In order to edit this value enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Timer Max.

PROGRAM Tmax P:Y  
Timer = XX.XXX

Press the ENT button in order to edit the maximum run timer's value.

After the ENT button is pressed, the display will read PROGRAM Tmax P:Y, Timer = XX.XXX (where Y is the current parameter and XX.XXX is the current timer's value).

Using the left and right arrow keys move the flashing cursor over the digit in the timer value that needs edited. Once the appropriate digit is highlighted, press the up and down arrows to change the digit's value. Proceed in this manner until all of the desired digits are edited.

TIMER MIN SAVED  
Writing....

Once the display shows the appropriate timer value, pressing the ENT button will store the new value to non-volatile memory and the user will be prompted to Press Any Key.


TIMER MIN SAVED  
Press Any Key

At this point any button may be pressed and the unit will return to the Program Menu.

During the editing process, if the ESC button is pressed, the unit will abort programming the Timer Max and return to the Program Menu.

## Interface Navigation Guide

### Timer Bump



Timer Bump defines an amount of time that a tool can run and that run will be ignored if the clutch does not fire (i.e. torque is not achieved). This timer may be used to eliminate nuisance rejects.

PROGRAM MENU  
Timer Bump

In order to edit this value enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Timer Bump.

PROGRAM Tbmp P:Y  
Timer = XX.XXX

Press the ENT button in order to edit the bump timer's value.

After the ENT button is pressed, the display will read PROGRAM Tbmp P:Y, Timer = XX.XXX (where Y is the current parameter and XX.XXX is the current timer's value).

Using the left and right arrow keys move the flashing cursor over the digit in the timer value that needs edited. Once the appropriate digit is highlighted, press the up and down arrows to change the digit's value. Proceed in this manner until all of the desired digits are edited.

TIMER BUMP SAVED  
Writing....


Once the display shows the appropriate timer value, pressing the ENT button will store the new value to non-volatile memory and the user will be prompted to Press Any Key. At this point any button may be pressed and the unit will return to the Program Menu.

TIMER BUMP SAVED  
Press Any Key

During the editing process, if the ESC button is pressed, the unit will abort programming the Timer Bump and return to the Program Menu.


## Interface Navigation Guide

### Start Current




The Start Current defines the amount of current that needs to be drawn by a brushless tool before the unit is considered to be in cycle. Once the tool starts drawing this amount of current, the run-timers will start.

(Note: The Start Current value is only used with brushless tools.)



After the ENT button is pressed, the display will read STRT CURRENT P:Y, TRIP = X.XX A (where Y is the current parameter and X.XX is the amperage value).

Use the left or down arrow key to lower this value. The right or up arrow keys will raise the value. Proceed in this manner until the appropriate current is displayed.




During the editing process, if the ESC button is pressed, the unit will abort programming the Start Current and return to the Program Menu.



## Interface Navigation Guide

### Min Current



The Min Current defines the minimum amount of current that needs to be drawn by a brushless tool when the tools clutch engages. This threshold can be used as a secondary check for the tool's clutch setting. (**Note:** The

Min Current value is only used with brushless tools.)

**PROGRAM MENU**  
Min Current

In order to edit this value enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Shut-Off Current.

**MIN CRNT P:Y**  
TRIP = X.XX A

Press the ENT button in order to edit the Min Current's value.

After the ENT button is pressed, the display will read MIN CRNT P:Y, TRIP = X.XX A (where Y is the current parameter and X.XX is the amperage value).

Use the left or down arrow key to lower this value. The right or up arrow key will raise the value. Proceed in this manner until the appropriate current is displayed.

**THRESHOLD SAVED**  
Writing....


Once the display shows the appropriate amperage value, pressing the ENT button will store the new value to non-volatile memory and the user will be prompted to Press Any Key. At this point any button may be pressed and the unit will return to the Program Menu.

**THRESHOLD SAVED**  
Press Any Key


During the editing process, if the ESC button is pressed, the unit will abort programming the Min Current and return to the Program Menu.

## Interface Navigation Guide

### Max Current




The Max Current defines the maximum amount of current that can be drawn by a brushless tool when the tool clutches out. This threshold can be used as a secondary check for the tool's clutch setting. (**Note:** The Max Current value is only used with brushless tools.)



After the ENT button is pressed, the display will read MAX CURRENT P:Y, TRIP = XX.XX A (where Y is the current parameter and XX.XX is the amperage value).


Use the left or down arrow key to lower this value. The right or up arrow key will raise the value. Proceed in this manner until the appropriate current is displayed.



During the editing process, if the ESC button is pressed, the unit will abort programming the Max Current and return to the Program Menu.


## Interface Navigation Guide

### Batch Count




The Batch Count is typically programmed to be the number of fasteners in a given assembly. A Cycle Accept signal will be generated each time a proper fastening occurs. A Batch Accept however, will occur when the

count reaches the batch value.



After the ENT button is pressed, the display will read BATCH COUNT P:Y, Batch = XXX (where Y is the current parameter and XXX is the number of fasteners in a batch).


Use the up or down arrow key to raise or lower the batch value by 1. The left and right arrow keys will raise or lower the value by 10. Proceed in this manner until the appropriate batch value is displayed.




During the editing process, if the ESC button is pressed, the unit will abort programming the Batch Count and return to the Program Menu.

## Interface Navigation Guide

### Globalize




Often, when multiple parameter sets are used, only one or two variables within the parameter sets needs to vary. It's very common to have everything within multiple parameter sets be identical except for a variation in the batch count. If this is the case, globalizing a parameter set may help to speed up the programming process. When globalization is used a parameter set is copied to all of the other parameters.



After the ENT button is pressed, the display will read GLOBALIZE PARAM, Parameter = Y (where Y is the parameter that will be copied to all other parameters if selected).


Using the arrow keys select the parameter set to be copied.



During the editing process, if the ESC button is pressed, the unit will abort programming the Globalization and return to the Program Menu.

## Interface Navigation Guide

### Relay & Beep



The output relays in this system can be programmed to be either momentary or latching. If the relays are momentary they will close briefly (200ms) when an event occurs. When set to latching, the relay closes and remains that way until the tool starts running again.

The beeper in this system can be programmed to double-beep when a batch accept occurs.

PROGRAM MENU  
Relay & Beep

In order to edit these items enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Relay & Beep.

PGM RELAY/BEEPER  
RLY XXX BEEP YYY

Press the ENT button in order to edit relay or beeper settings.

After the ENT button is pressed, the display will read PGM RELAY/BEEPER, RLY XXX BEEP YYY (where XXX is either MOM for momentary or LAT for latching and YYY is either ON or OFF).

Using the arrow keys set the desired relay and beeper setting.

RLY/BEEPER SAVED  
Writing....


Once the display shows the appropriate settings, pressing ENT will save the settings to non-volatile memory and the user will be prompted to Press Any Key. At this point any button may be pressed and the unit will return to the Program Menu.

RLY/BEEPER SAVED  
Press Any Key

During the editing process, if the ESC button is pressed, the unit will abort programming the Relay & Beeper and return to the Program Menu.

## Interface Navigation Guide

### Parameter Select



This unit can be programmed to change parameter either through the keypad or remotely through the I/O.

PROGRAM MENU  
Parameter Select

In order to edit this function, enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Parameter Select.

PARAMETER SELECT  
Remote I/O

Press the ENT button in order to edit the Parameter Select.

After the ENT button is pressed, the display will read PARAMETER SELECT (Keypad or Remote I/O).

Using the arrow keys set the desired parameter select (either Keypad or Remote I/O). The Keypad option will allow the operator to change the parameter with the left and right arrow keys from the home screen while the unit is in the locked position. (See page 15 for more information on the Keypad.) The Remote I/O option will allow the parameter to be switched only through the I/O. (See page 45 - 46 for more information on the Remote I/O)

Parameter Select  
Writing....


Once the display shows the appropriate setting, pressing ENT will save the settings to non-volatile memory and the user will be prompted to Press Any Key. At this point any button may be pressed and the unit will return to the Program Menu.

DIRECTION SAVED  
Press Any Key


During the editing process, if the ESC button is pressed, the unit will abort programming the Parameter Select and return to the Program Menu.

## Interface Navigation Guide

### Count Direction




This unit can be programmed to count up from zero until the batch is reached or count down to zero.



After the ENT button is pressed, the display will read COUNT DIRECTION, Count XXX (where XXX is either UP or DOWN).


Using the arrow keys set the desired count direction (either up or down) .



During the editing process, if the ESC button is pressed, the unit will abort programming the Count Direction and return to the Program Menu.

## Interface Navigation Guide

### New Password



In order to enter the programming mode, either the key-switch was used or a password was entered. The default password of 0104 can be overwritten and set to any four digit number.

PROGRAM MENU  
New Password

In order to change the password, enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, New Password.

PROGRAM PASSWORD  
0 \* \* \*

Press the ENT button in order to edit the password.

After the ENT button is pressed, the display will read PROGRAM PASSWORD, 0 \* \* \*.

The left and right arrow keys can be used to select any of the four digits in the password. Once the desired digit is highlighted, the up and down arrow keys will allow the user to change that digit. Only the digit being edited will be visible. The other digits will be obscured and asterisks will appear as a placeholder.

PROGRAM PASSWORD  
Writing....

Once the desired password has been entered, pressing ENT will save the settings to non-volatile memory and the user will be prompted to Press Any Key. At this point any button may be pressed and the unit will return to the Program Menu.


PROGRAM PASSWORD  
Press Any Key

During the editing process, if the ESC button is pressed, the unit will abort programming a New Password and return to the Program Menu.




## Interface Navigation Guide

### Digital Inputs



The Digital Inputs menu option is a trouble shooting mode. If this item is selected, the signals that the tool is sending the TS III can be monitored.



Once in this mode, the left side of the display will show the state of the tool's In Cycle run. That side of the display will either read RUN ON or RUN OFF. In a brush tool, this signal should be off until the run switch is activated (either through a lever or push to start).


In a brushless tool, the left side of the display will always read RUN ON because most brushless tools constantly issue a run request even if the tool's run switch is off.

The right side of the display shows the state of the tool's clutch signal. This message will read BRK OFF most of the time. When a tool clutch engages (either brush or brushless) this message will briefly read BRK ON.

If the ESC button is pressed, the unit will return to the Program Menu.

## Interface Navigation Guide


### Current Draw



The Current Draw menu option is a trouble shooting mode.

This mode can be particularly handy when deciding how to program the Start Current, Min Current, and Max Current for a brushless tool.

If this item is selected, the TS III will act like a current meter showing the user how much current is being drawn by the tool (either brush or brushless).



In order to view this value, enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, Current

Draw.


Press the ENT button in order to monitor the tool's current use.

Once in this mode, the bottom line of the LCD will display the current draw in amps. This value will be constantly updated while in this mode.

If the ESC button is pressed, the unit will return to the Program Menu.


## Interface Navigation Guide

### View Run Time



Another trouble shooting mode/programming aid is the View Run Time mode.

In this mode, the display will show how long the tool ran during the previous fastening cycle.




Once in this mode, the bottom line of the LCD will display the amount of time that elapsed during the last fastening cycle. This value will be updated automatically each time the tool runs.

This information can be very useful in determining what values should be used for the minimum and maximum run times.

If the ESC button is pressed, the unit will return to the Program Menu.

## Interface Navigation Guide


### View Shutoff I



Another trouble shooting mode/programming aid is the View Shutoff I mode.

This mode can be particularly handy when deciding how to program the Min Current, and Max Current for a brushless tool.

If this item is selected, the TS III will act like a current meter showing the user the current level when the tool shuts off or the clutch engaged. (**Note:** The View Shutoff I Current value is only used with brushless tools.)



In order to view this value, enter the Program Menu and press an arrow key until the display reads PROGRAM MENU, View Shutoff I.

Press the ENT button in order to monitor the tool's current use.


Once in this mode, the bottom line of the LCD will display the current level (in amperage) when the tools clutch engaged. This value will be updated automatically each time the tool runs.

This information can be very useful in determining what values should be used for the Min Current and Max Current.

If the ESC button is pressed, the unit will return to the Program Menu.


## Interface Navigation Guide

### LCD Contrast



The LCD display can be adjusted so that the text is darker or lighter by accessing the LCD Contrast feature.

In this mode, the display will show a value that represents a contrast setting for the display. As that value is altered the user can see what effect it has on the view-ability of the display.



## PC Interface

---

### Introduction

The Cyber Qualifier software is not included with your purchase, however it can be used to adjust your Parameter Sets.

### Requirements

The Cyber Qualifier software needs to run on a computer that is running Windows 9X, Windows NT, Windows ME, Windows 2000 or Windows XP. The computer should have at least 32 MB of RAM memory and have 5MB of hard disk space available. The computer will also need to have the display set to at least an 800 x 600 resolution. A high color setting is recommended (16 bits or better).

A free comm. port is necessary in order to communicate with a Qualifier. Complications can arise if another program is attempting to use the comm. port while the Cyber Qualifier software is running.

In order to use the Cyber Qualifier software, a modular phone cable RJ11 (wired straight through) and an RJ11 to DB9 converter must be used.

### Installing the Software

To install the software on a computer with a Windows operating system, run the SETUP.EXE program on the Cyber Qualifier CD. The setup program will lead the installer through the installation. Depending on which version of Windows is being used, the machine may need to be restarted once during the installation and the installation process re-initiated. Make sure that no other software is running on the target machine during the installation process.

### Running the Software



CyberQ

After the program is installed, a new entry will be found under the Window's Start Menu. To start the program, press the Window's Start Button. On the menu that appears choose Programs and then click on CyberQ.

Alternately, the user can find and then double-click on the CyberQ icon. This will also start the application.




## Operations Graphs

Note: All of the Operations Graphs are for Brush Style Electric Tools except where it is noted. Brushless tools chart would be similar but not the same as Brush tools. Please call ASG Customer Service if there are any questions. (888) 486-6163

### Approved Tightening


The following graph demonstrates a tightening cycle that would be accepted by the TS III Qualifier. The In Cycle current level rises and runs for a time greater than the minimum timer ( $T_{min}$ ) and less than the maximum timer ( $T_{max}$ ). When the clutch shuts off the In Cycle current, rapidly drops off and the Clutch Signal current increases. The Clutch Signal represents the inductive current spike that rises when the clutch shuts off the tool, the clutch shut off must occur after  $T_{clutch1}$  and before  $T_{clutch2}$ .





## Operations Graphs

### Brushless Approved Tightening Overview




- ① **Start Current** - This is the Start Timer when the running current cross this threshold the TS-III's timer starts. (See page 24 for more information)
- ② **Timer Bump** - This is the Timer Bump designed to ignore the first X amount of time in a fastening cycle. (See page 23 for more information)
- ③ **Start Point** - The TS-III's timer will not start until load is applied; this results in a more consistent timer reducing the potential of free run errors.
- ④ **Timer Min** - Timer Min defines the minimum amount of time a tool has to run during a fastening cycle to be considered a good fastening. (See page 21 for more information)
- ⑤ **Timer Max** - Timer Max defines the maximum amount of time a tool can run during a fastening cycle to be considered a good fastening. (See page 22 for more information)
- ⑥ **Accept Range** - The peak current must occur within this Accept Range between the Min and Max Current for a successful fastening cycle.
- ⑦ **Min Current** - The Min Current defines the minimum amount of current that needs to be drawn by a brushless tool when the tool clutches out. (See page 25 for more information)
- ⑧ **Max Current** - The Max Current defines the maximum amount of current that can be drawn by a brushless tool when the tool clutches out. (See page 26 for more information)

## Operations Graphs

### Approved Tightening

(Using Timer Bump)

In graph below represents the use of Timer Bump. The Tbump is essential when a screw presenter is combined with the TS III Qualifier. The graph shows how using the Tbump function during an assembly process will not affect a properly assembled screw. However, when a screw is picked up from the presenter, typically the driver is quickly run to locate the screw on the bit. If the Tbump function is not turned on then a reject will be generated. When a time limit is programmed into Tbump, the In Cycle current is ignored for the duration of the Tbump time. (Note: If the Clutch Signal current rises during Tbump indicating a clutch shut off, the tightening cycle will be rejected.)




## Operations Graphs

### Not Approved Tightening

(Incomplete Cycle, No Clutch Signal or Stripped Threads)

The In Cycle current curve shown in the chart below displays a typical incomplete cycle. In this case, the In Cycle current lasts long enough to satisfy TMin. However, the tool's clutch never engages and therefore the inductive current spike never occurs. TClutch is violated and the fastener would be rejected.




## Operations Graphs

### Not Approved Tightening

(Double Hit or Cross Thread)

Attempting to re-tighten a fastener that has already been tightened with an electric tool creates a current signature similar to the one below. The In Cycle current rises very rapidly and then drops quickly when the clutch shuts the tool off. Since the clutch turns the tool off almost instantly, the forward current is present only briefly and does not run long enough to satisfy TMin.



## Specifications

---

### Input Specifications:

Input Voltage Range	85-264 VAC
Input Current	2.2A/115VAC 1.1A/230VAC
Frequency	47-440Hz
Power Factor	$\geq 0.96/230V$ , $\geq 0.98/115V$

### Output Specifications:

Output Voltage (Low)	20VDC
Output Voltage (High)	30VDC
Output Power	150 Watts
Minimum Load	0A
Output Tolerance	+/- 2%
Ripple Noise	150mVp-p, typical
Overload Protection	105~150%, Constant Current Limit Auto Recovery
Setup/Rise/Holdup(230VAC)	600ms/30ms/20ms

### General Specifications:


Input/Output Isolation	I/P-O/P 3000VAC I/P-G 1500VAC O/P 0.5KVAC
Efficiency	80% typical
Switching Frequency	135Khz (fixed, typical)
MTBF	191,800 Hrs (21.9 years)



## Troubleshooting

### Troubleshooting

**Q.** When trying to AutoCal I see the following screen, what does this mean?



**A.** If Check Clutch appear while performing an AutoCal there are two possible symptoms. One, a Brush type tool could be connected to the TS-III Qualifier, which is designed for a Brushless tool; or the Brushless tool has not been modified for use with the TS-III Qualifier. If the Brushless Driver has not been modified for the Qualifier please call ASG Customer Service (888) 486-6163 to send your tool in for the modification to be performed.

**Q.** When the tools runs in free air the unit continuous signals reject and the alarm sounds.

**A.** The Start Current might be set at the same amperage level that the tool draws while running under no load (free in the air). The Start Current should be adjusted either slightly above the no load free speed of the tool or slightly below. To establish the no load free speed use the Current Draw option located in the Programming Menu. (See Page 34 for more information)

## ■ Troubleshooting

---

### Troubleshooting

**Q.** I changed from HI Speed to LO Speed and now I keep getting rejects.

**A.** The TS-III Qualifier monitors current over a period of time to verify a good cycle. When the speed of the tool is changed the result is that the insertion of the fastener will take more or less time. The fastener characteristics associated with the new speed setting will not match up with the characteristics used to establish the parameters with the previous speed setting. Whenever the speed setting is adjusted another AutoCal should be performed with the new speed setting selected. This will ensure the proper times are established for a good cycle.

**Q.** I turned ON my Slow Start and now I keep getting rejects.

**A.** The TS-III Qualifier monitors current over a period of time to verify a good cycle. When the Slow Start is enable the start of the tool is changed, and the result is that the insertion of the fastener will take more time. The fastener characteristics associated with the Slow Start setting will not match up with the characteristics used to establish the parameters with the previous setting. Whenever the Slow Start setting is enabled another AutoCal should be performed with the new Slow Start turned ON. This will ensure the proper times are established for a good cycle.



## Index

---

### **A**

<u>AC INPUT</u> .....	9
<u>ACCEPT</u> .....	13
<u>ADVANCED OPERATIONS</u> .....	16 - 37
<u>ARROWS</u> .....	8
<u>AUTOCAL</u> .....	17, 19 - 20

### **B**

<u>BASIC OPERATIONS</u> .....	15
<u>BAT ACC</u> .....	13
<u>BATCH</u> .....	12, 18, 27
<u>BEEP</u> .....	18, 29

### **C**

<u>CAUTIONS</u> .....	5
<u>CHANGE PARAMETER</u> .....	15, 30, 46
<u>CHANGE PASSWORD</u> .....	32
<u>CHECK CLUTCH</u> .....	47
<u>CLEAR BATCH</u> .....	15
<u>CONFIGURATION</u> .....	3
<u>CONTRAST</u> .....	18, 37
<u>CONTROL PANEL</u> .....	8 - 9, 37
<u>CONNECTION PROCEDURE</u> .....	9 - 10
<u>COUNT</u> .....	12, 18, 27, 31
<u>CURRENT DRAW</u> .....	18, 34
<u>CYBER QUALIFIER SOFTWARE</u> .....	38 - 39
<u>CYC ACC</u> .....	13

### **D**

<u>DEFAULT PASSWORD</u> .....	6, 16, 32
<u>DIGITAL INPUTS</u> .....	18, 33

### **E**

<u>ENT</u> .....	8
<u>ESC</u> .....	8

### **F**

<u>FRONT PANEL</u> .....	9
--------------------------	---

### **G**

<u>GRAPHS</u> .....	40 - 44
<u>GLOBALIZE</u> .....	18, 28

### **H**

<u>HOME SCREEN</u> .....	11 - 14
--------------------------	---------

## Index

---

### **I**

<u>I/O CONNECTOR</u> .....	9 - 46
<u>IMAX</u> .....	14, 26
<u>IMIN</u> .....	14, 25
<u>INPUTS</u> .....	18, 33
<u>INSTALLING THE SOFTWARE</u> .....	38
<u>INTERFACE NAVIGATION GUIDE</u> .....	11 - 37
<u>INTRODUCTION</u> .....	3

### **J**

### **K**

<u>KEYPAD</u> .....	8
<u>KEYSWITCH</u> .....	9, 16

### **L**

<u>LCD CONTRAST</u> .....	18, 37
---------------------------	--------

### **M**

<u>MAIN POWER SWITCH</u> .....	9 - 10
<u>MAX CURRENT</u> .....	17, 26
<u>MIN CURRENT</u> .....	17, 25

### **N**

<u>NEW PASSWORD</u> .....	18, 32
---------------------------	--------

### **O**

<u>OPERATIONS GRAPHS</u> .....	40 - 44
<u>OPTIONS (SOFTWARE)</u> .....	38 - 39
<u>OUTPUT SPECIFICATIONS</u> .....	46

### **P**

<u>PARAMETER SELECT</u> .....	12, 15, 18, 30, 46
<u>PASSWORD</u> .....	16, 18, 32
<u>PC INTERFACE</u> .....	38 - 39
<u>POWER CORD</u> .....	3, 9
<u>POWER-UP SEQUENCE</u> .....	11
<u>PROGRAM MENU</u> .....	17 - 18

### **Q**

<u>QUICK START GUIDE</u> .....	6 - 7
--------------------------------	-------

## Index

---

### **R**

<u>REAR PANEL</u> .....	9
<u>REJECT</u> .....	14
<u>RELAYS</u> .....	18, 29
<u>REQUIREMENTS</u> .....	26
<u>RESET BATCH</u> .....	15
<u>RS-232 CONNECTOR</u> .....	9, 38, 46
<u>RUN TIME</u> .....	18, 35

### **S**

<u>SET BATCH</u> .....	27
<u>SET-UP PROCEDURE</u> .....	10
<u>SHUTOFF I</u> .....	18, 36
<u>SOFT START</u> .....	9
<u>SOFTWARE</u> .....	38 - 39
<u>SPECIFICATIONS</u> .....	45 - 46
<u>SPEED SWITCH</u> .....	9
<u>START CURRENT</u> .....	17, 24
<u>STATUS</u> .....	12 - 14

### **T**

<u>TCLU</u> .....	14
<u>TIMER BUMP</u> .....	17, 23
<u>TIMER MAX</u> .....	17, 22
<u>TIMER MIN</u> .....	17, 21
<u>TJOG</u> .....	9, 14, 18
<u>TMAX</u> .....	9, 14, 18
<u>TMIN</u> .....	9, 14, 18
<u>TOOL/POWERSUPPLY CONNECTOR</u> .....	43
<u>TROUBLESHOOTING</u> .....	47 - 48

### **U**

### **V**

<u>VIEW RUN TIME</u> .....	18, 35
<u>VIEW SHUTOFF I</u> .....	18, 36
<u>VIEW TOTAL</u> .....	12

### **W**

<u>WARNINGS</u> .....	4
-----------------------	---

### **X,Y,Z**

